

**To adjust idling speed.** To adjust the idling speed, first go for a short run to warm up the engine to the normal temperature. Screw in the slow running adjuster 'A' (Fig 20) for a fast idling speed. Finally, readjust the slow running screw until even running at slow speeds results.

Sluggish accelerator operation can be caused by a sticking cable. To remedy, the cable is detached from the carburettor, and WD40 oil sprayed inside the cable (and from the accelerator end) casing until the inner cable moves freely.

*NOTE: This work should be carried out only by a competent mechanic.*




Fig 20