Service Schedules

	A At 450 miles 750 km	B Every 6000 mi. 10000 km or 6 months	C Every 12000 mi. 20000 km or 12 months
General			
Check for petrol, oil or water leaks	•	•	•
Inspect all hoses, fittings and connections	•	•	•
Engine			
Check for oil leaks	•	•	•
Drain off engine oil and refill	•	•	•
Renew oil filter element	•	•	•
Check coolant level, top up at header tank when cold	•	•	•
Check coolant system for leaks	•	•	•
Check tension of drive belts, check for wear	•	•	•
Inspect drive belts for wear	•	•	•
Lubricate throttle linkage	•	•	•
Inspect and lubricate accelerator pedal linkage		•	•
Clean petrol pump filter and bowl	•	•	•
Clean out carburetter			•
Change fuel filter if necessary			•
Clean air filter		•	•
Change air filter element			•
Tighten cylinder head bolts, manifold flange nuts and exhaust system mountings	•	•	•
Clean oil filler cap, wash gauze in petrol and lightly oil		•	•
Clean emission control valve where applicable		•	•
Adjust valve tappet clearances	•	•	•
Adjust carburetter settings and idling speed	•	•	•
Check angle of dwell	•	•	•
Adjust ignition timing	•	•	•
Check distributor points	•	•	•
Clean and adjust sparking plugs		•	•
Renew sparking plugs			•
Oil distributor cam, pivots and automatic advance	•	•	•
Clean coil, distributor cap and H.T. leads		•	•
Check clips on petrol filler hoses, petrol feed hoses and breather pipe	•	•	•

Special attention needed with emission control carburation