


Wiring Diagram



IGNITION SWITCH OPERATION	
POSITION	CONNECTION
OFF	
AUX	4-3
IGN	4-3,1
START	4-1,2

WIPER SWITCH OPERATION	
POSITION	CONNECTION
OFF	3-4
SLOW	3-1
FAST	2-1
INTERMITTENT	9-7, 3-8

TERMINATIONS MARKED G2, P7 etc ARE WIRED TO THEIR RESPECTIVE TERMINAL ON THE FUSEBOXES. ALL 'G' CONNECTIONS ARE COLOURED GREEN, AND 'P' CONNECTIONS PURPLE. ALL CHASSIS CONNECTIONS ARE COLOURED BLACK.

COLOUR KEY			
N	BROWN	Y	YELLOW
P	PURPLE	R	RED
W	WHITE	LG	LIGHT GREEN
U	BLUE	B	BLACK
G	GREEN		